

Late Model Corvair Towing Hitch

This is being shown with bumper unattached. The Hitch installs in upswept position—do not try to install inverted as you need three bolt points to secure hitch! The hitch can be installed without removing bumper. The center rear bolt through bumper must be removed, this may be easier with bumper off due to corrosion locking the nut, but is not always the case.

Drill two 3/8 inch holes in pinchweld beneath rear air grill. Simply center hitch off the centerline rear bumper bolt and mark. This also can be done by mounting hitch to underside center bumper bolt (the original stainless carriage bolt must be removed from bumper first and replaced with chrome bolt, threads facing down) insert through elongated hole in hitch and drill in place.

Insert two Grade 5 bolts through matching hitch tabs in lower pinchweld using two flat washers and one lockwasher on the backside. Tighten securely. To re-install air grill you must cut a matching notch in upper part of grill. Some prefer to find a second grill to do this with to preserve the original grill.

This hitch is intended for no more than 1200lbs/300 lbs tongue weight.

